

| Pump Model | Part Name                | Standard Part Code | HS1 Part Code |
|------------|--------------------------|--------------------|---------------|
| 1.5/1B-AH  | Expeller                 | B028A05            | B028HS1A05    |
|            | Expeller Ring            | B029A05            | B029HS1A05    |
|            | Frame Plate Liner Insert | B1041A05           | B1041HS1A05   |
| 2/1.5B-AH  | Expeller                 | B028A05            | B028HS1A05    |
|            | Expeller Ring            | B029A05            | B029HS1A05    |
|            | Frame Plate Liner Insert | B15041A05          | B15041HS1A05  |
| 3/2C-AH    | Expeller                 | C028A05            | C028HS1A05    |
|            | Expeller Ring            | C029A05            | C029HS1A05    |
|            | Frame Plate Liner Insert | C2041A05           | C2041HS1A05   |
| 4/3C-AH    | Expeller                 | CAM028A05          | CAM028HS1A05  |
|            | Expeller Ring            | CAM029A05          | CAM029HS1A05  |
|            | Frame Plate Liner Insert | D3041A05           | D3041HS1A05   |
| 4/3D-AH    | Expeller                 | D028A05            | D028HS1A05    |
|            | Expeller Ring            | D029A05            | D029HS1A05    |
|            | Frame Plate Liner Insert | D3041A05           | D3041HS1A05   |
| 6/4D-AH    | Expeller                 | DAM028A05          | DAM028HS1A05  |
|            | Expeller Ring            | DAM029A05          | DAM029HS1A05  |
|            | Frame Plate Liner Insert | E4041A05           | E4041HS1A05   |
| 6/4E-AH    | Expeller                 | E028A05            | E028HS1A05    |
|            | Expeller Ring            | E029A05            | E029HS1A05    |
|            | Frame Plate Liner Insert | E4041A05           | E4041HS1A05   |
| 8/6E-AH    | Expeller                 | EAM028A05          | EAM028HS1A05  |
|            | Expeller Ring            | EAM029A05          | EAM029HS1A05  |
|            | Frame Plate Liner Insert | F6041A05           | F6041HS1A05   |
| 10/8F-AH   | Expeller                 | F028A05            | F028HS1A05    |
|            | Expeller Ring            | F029A05            | F029HS1A05    |
|            | Frame Plate Liner Insert | F8041A05           | F8041HS1A05   |
| 12/10ST-AH | Expeller                 | SH028A05           | SH028HS1A05   |
|            | Expeller Ring            | G029A05            | G029HS1A05    |
|            | Frame Plate Liner Insert | G10041A05          | G10041HS1A05  |
| 14/12ST-AH | Expeller                 | SH028A05           | SH028HS1A05   |
|            | Expeller Ring            | G029A05            | G029HS1A05    |
|            | Frame Plate Liner Insert | G12041A05          | G12041HS1A05  |
| 16/14TU-AH | Expeller                 | TH028A05           | TH028HS1A05   |
|            | Expeller Ring            | H029A05            | H029HS1A05    |
|            | Frame Plate Liner Insert | H14041A05          | H14041HS1A05  |
| 20/18TU-AH | Expeller                 | TH028A05           | TH028HS1A05   |
|            | Expeller Ring            | H029A05            | H029HS1A05    |
|            | Frame Plate Liner Insert | H18041A05          | H18041HS1A05  |